VW / PORCHE Denso Starter INSTRUCTIONS

TECH DEPT
(630) **957-4019**

XS Torque
9534



#9534
VW / PORSCHE Air Cooled

Wiring Instructions:

1. Install a jumper wire from the “Bat” terminal connection on the starter solenoid to the “IGN” terminal.

[OPTIONAL: Run the “switch” wire from the starter relay to the “IGN” terminal on the starter solenoid.]

2. Connect the positive battery wire to the “BAT” terminal on the starter solenoid.



Need Help? Call our Tech Line

(630) 957-4019

Email : tech@powermasterperformance.com

Battery Condition:
Charge and Load Test Battery. A weak or discharged battery can cause starter failure.

Grounds:
Battery must be grounded to engine block.

Cables and Wiring:
All terminals should be crimped and soldered. Connections clean and tight.

Do Not over tighten small Ign terminal on starter.

Failure to follow these instructions may void your warranty