





advanced FLOW engineering

Instruction Manual P/N: 51/54-12642-B / 52-12642-H

Make: **Ford** Model: **F-150** Year: **2015** Engine: **V6-2.7L (tt) / 3.5L (tt) EcoBoost**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect the negative battery terminal before proceeding.

NOTE: Retain factory parts for future use.

Label	Qty.	Description	Part Number
A1	2	Pro DRY S Air Filter	21-90069 (Gray Media) (51-12642-B/52-12642-H)
A2	2	Pro 5R Air Filter	24-90069 (Blue Media) (54-12642/52-12642-H)
B	1	Housing	05-12642L3
C	1	Tube	05-12642B1/H1
D	1	Coupling, Straight	05-01242
E	1	Coupling, Reducer	05-01224
F	1	Coupling, Reducer	05-00636
G	2	Clamp #32	03-50016
H	1	Clamp #52	03-50008
I	2	Clamp #60	03-50002
J	1	Clamp #72	03-50010
K	1	Seal Trim (22.5 Inches)	05-00072
L	1	Cover	05-12188-B (*Optional)
M	3	Screws	03-50113 (*Optional)
N	1	Grommet	03-50050
O	1	Tube	05-12642B2/H2

Installation will require the following tools:

8mm Nut Driver, Flat Head Screwdriver

***Optional cover 54-12188**

Note: Legal in California for use on race vehicles only. The use of this device on vehicles used on public streets or highways is strictly prohibited in California and others states that have adopted California emission regulations.





Figure A

Refer to Figure A for steps 1-4

Step 1: Disconnect the Manifold Air Pressure (MAP) sensor plug from stock air box. ①

Step 2: Loosen the OE intake clamps using an 8mm nut driver from the left and right side runners. ②

Step 3: Unclamp the top portion of the OE air box. ③

Step 4: Remove the OE intake and the top portion of the OE air box by pulling straight up and out of the vehicle.



Refer to Figure B for step 5

Step 5: Carefully remove plastic wire harness clips from back edge of lower airbox.



Figure C

Refer to Figure C for steps 6-7

Step 6: Install aFe housing and fasten clips.

Step 7: Insert filters and place clamps loosely.




Figure D

Refer to Figure D for steps 8-9

Step 8: Remove the MAP sensor from the OE intake 1/4 turn counter-clockwise.

Step 9: Install the MAP sensor on the rear aFe intake tube using the provided grommet. The grommet can be held inside the tube to give support while inserting.



Refer to Figure E for steps 10-14

Step 10: Install the small straight coupling on the cross over tube, install clamps but do not tighten.

Step 11: Fit tubes into the remaining couplers. Adjust for best fit and tighten all clamps.

Step 12: Connect sensor harness.

Step 13: Install edge trim on housing if no cover is to be used.

Step 14: Remove trim if using optional cover.

This page left blank intentionally.

Pro DRY S Air Filter



P/N: 21-90069

Pro 5R Air Filter



P/N: 24-90069

Pro-GUARD 7 Air Filter



P/N: 72-90069

Intake Cover



P/N: 54-12188

Pre-Filter



P/N: 28-10213

Throttle Body Spacer



P/N: 46-33017

Transmission Pan



P/N: 46-70172

Y-Pipe



P/N: 48-43008

Y-Pipe



P/N: 48-43010

Air Intake



P/N: 54-32642-B

Air Intake



P/N: 54-73112


Warranty

General Terms:

- aFe warrants their products to be free from manufacturer's defects due to workmanship and material.
- This warranty applies only to the original purchaser of the product and is non-transferrable.
- Proof of purchase of the aFe product is required for all warranty claims.
- Warranty is valid provided aFe instructions for installation and/or cleaning were properly followed.
- Proper maintenance with regular inspections of product is required to insure warranty coverage.
- Damage due to improper installation, abuse, unauthorized repair or alteration is not warranted.
- Incidental or consequential damages or cost, including installation and removal of part, incurred due to failure of aFe product is not covered under this warranty.
- All warranty is limited to the repair and/or replacement of the aFe part. To request Return Goods Authorization ("RGA"), email RGA@afepower.com or call (951)493-7100. Upon receipt of the RGA, you must return the product to the address provided in the RGA, freight prepaid and accompanied with a dated proof of purchase and the RGA. Upon receipt of the defective product and upon verification of proof of purchase, aFe will either repair or replace the defective product within a reasonable time, not to exceed thirty days.

Product Category	P/N Prefix	Warranty duration
Direct OE Replacement Filters	10, 11, 30, 31, 71, 73	Life of the vehicle
Racing Filters	18	1 year
Universal	21, 24, 72	2 years
Air Intake Systems	50, 51, 54, 55, 75	2 years
Exhaust Systems	49	2 years
Intercoolers & Intercooler Tubes	46-2	2 years
Intake Manifolds	46-1	2 years
Differential Cover	46-7	Life of the vehicle
Exhaust Manifolds	46	2 years
Throttle Body Spacers	46-3	2 years
Fluid Filters	44	90 days
Pre-Filters	28	2 years
Heavy Duty OE Replacement	70	2 years
PowerSports OE Replacement	81, 87	2 years
PowerSports Intake Systems	85	2 years

No other warranty expressed or implied applies nor is any person or advanced FLOW engineering authorized to assume any other warranty. Some States do not allow the exclusion or limitation of incidental or consequential damages or do not allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State.



advanced FLOW engineering, inc.
252 Granite Street Corona, CA 92879
TEL: 951.493.7155 • TECH: 951.493.7100
E-Mail: Tech@aFepower.com