



# INSTALLATION INSTRUCTIONS

## MSD Bolt-Down Cap Kit, PN 8838

For Large Ford Caps and MSD Cap-A-Dapt, PN 8420, PN 8445

### Parts Included:

2 - Cap Retainers  
2 - Spacer Adapters

2 - Screws  
2 - Washers

This Bolt-Down Cap Kit allows the spring clips to be removed and replaced with a bolt-down method resulting in a secure cap installation.

1. Use a small screwdriver to pry and twist the original spring clips from the spacer ring.
2. Install the shorter adapter into the spacer with the stepped boss facing up. The adapter will only fit one way and will snap into place.
3. Install the distributor cap. Position the hold down adapter on to the cap and screw it down.  
Note that the two adapters may not make full contact between each other.

### Installing the Bolt-Down Cap Kit



Remove Spring Clip



Install Adapter



Install Cap and Adapter