



1993-96 Chevy Impala SS 5.7L
Shorty Headers
Part # 1595,15950



Special Tools
Required:

- Saws-All

Install Time:

Approximately
2 Hours

Difficulty:

3 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

STEP 1

- Lift vehicle as high as possible, then disconnect the negative battery terminal.

STEP 2

- Disconnect the steering shaft, then remove the exhaust manifold flange nuts at the collectors. Disconnect the slip fit connection behind the catalytic converters and remove the Y-Pipe.

STEP 3

- Remove the air tubes, plug wires and plugs. Disconnect oxygen sensor plugs from the back of the engine.

STEP 4

- Remove the driver side exhaust manifold bolts and remove the manifold from the top of the engine compartment.

STEP 5

- Remove the passenger side EGR tube, dipstick, alternator and bracket. Remove exhaust manifolds and remove the manifold from the bottom of the engine compartment.

STEP 6

- With the exhaust manifolds out of the vehicle, remove the oxygen sensors from the stock exhaust manifolds and install them into the BBK Headers. ***NOTE!!! Be sure to add a small amount of anti-seize to the top thread of each oxygen sensor using the supplied anti-seize packet. As you thread the oxygen sensor back into the part the anti-seize will spread evenly throughout the threads.*** Be sure to make sure that the cylinder head flange surface is free of debris and is ready to reassemble.

STEP 7

- Using the supplied gaskets and bolts, install the BBK Headers starting all the bolts hand tight, then tighten to factory specs.

STEP 8

- Once the headers are in place install the EGR Tube, dip stick, alternator, air tubes, plugs and wires. Connect the oxygen sensor plugs and steering shaft at this time.

Caution

Use of heat shielding may be needed for oxygen sensor wires & passenger side plug wires



Join our Facebook page
www.facebook.com/bbkperformance



Follow us on Twitter
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube
www.youtube.com/bbkperformance

GO TO NEXT PAGE

WWW.BBKPERFORMANCE.COM

For any questions, email us:
tech@bbkperformance.com

installation instructions

1

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-081

1993-96 Chevy Impala SS 5.7L

Shorty Headers

Part # 1595,15950



STEP 9

- Before installing the factory Y-Pipe you must cut the passenger sides exhaust tube just below the flex tube about 5inches. This will allow the supplied slip tube to be put into place.

STEP 10

- Install the supplied slip tube onto the modified Y-Pipe and gently tighten using the supplied clamp to allow some movement for adjustment. Install Y-Pipe hand tighten fasteners. Once the proper fitment is achieved tighten to factory specs.

STEP 11

- Start the vehicle and check for leaks. Re-torque the header bolts after 500 miles of driving.

Revised 2/25/2013



Join our Facebook page
www.facebook.com/bbkperformance



Follow us on Twitter
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube
www.youtube.com/bbkperformance

WWW.BBKPERFORMANCE.COM

For any questions, email us:
tech@bbkperformance.com

installation instructions

2

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-081