

**Special Tools****Required:**

- No special tools required

Install Time:

Approximately
1 Hour

Difficulty:

2 out of 5

These X-Pipes are designed to be used with BBK's Coyote Swap Headers # 1634,16340

Follow these instructions carefully to ensure correct fitment and operation.

STEP 1

- With the vehicle raised in the air and supported on jack stands, pre-install the BBK Coyote Swap Headers and the supplied studs into the header collectors.

STEP 2

- Lift the X-Pipe assembly into place and support with a jack. Connect the front flanges of the X-Pipe to the header collectors. Slide the X-Pipe flanges over the header collector studs.

STEP 3

- Install the nuts and washers provided with the headers, onto the collector studs.

STEP 4

- Connect the rear of the X-Pipe to the stock flow tubes going to the mufflers.

STEP 5

- Position the X-Pipe for the best fit and ground clearance and tighten all the nuts and bolts.



Join our Facebook page
www.facebook.com/bbkperformance



Follow us on Twitter
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube
www.youtube.com/bbkperformance

WWW.BBKPERFORMANCE.COM

For any questions, email us:

tech@bbkperformance.com

installation instructions

1

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-177