



2011-2014 Ford 5.0L Coyote Swap

**X-Pipes****Part # 1786,1787****Special Tools****Required:**

- No special tools required

**Install Time:**Approximately  
1 Hour**Difficulty:**

2 out of 5

***These X-Pipes are designed to be used with BBK's Coyote Swap Headers # 1634,16340***

Follow these instructions carefully to ensure correct fitment and operation.

**STEP 1**

- With the vehicle raised in the air and supported on jack stands, pre-install the BBK Coyote Swap Headers and the supplied studs into the header collectors.

**STEP 2**

- Lift the X-Pipe assembly into place and support with a jack. Connect the front flanges of the X-Pipe to the header collectors. Slide the X-Pipe flanges over the header collector studs.

**STEP 3**

- Install the nuts and washers provided with the headers, onto the collector studs.

**STEP 4**

- Connect the rear of the X-Pipe to the stock flow tubes going to the mufflers.

**STEP 5**

- Position the X-Pipe for the best fit and ground clearance and tighten all the nuts and bolts.



Join our Facebook page  
[www.facebook.com/bbkperformance](http://www.facebook.com/bbkperformance)



Follow us on Twitter  
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube  
[www.youtube.com/bbkperformance](http://www.youtube.com/bbkperformance)

[WWW.BBKPERFORMANCE.COM](http://WWW.BBKPERFORMANCE.COM)

For any questions, email us:

[tech@bbkperformance.com](mailto:tech@bbkperformance.com)

installation instructions

1

**IMPORTANT:** All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-177