



#802410 Ford I-6 200/250 P/S Pump Bracket

Installation:

- 1) Attach the bracket to the driver's side mounting pad on the engine block with the two 5/16" bolts and washers.
- 2) Attach the P/S pump to the front of the bracket with either the 3/8" or M10 bolts depending on the P/S pump you are using.



Borgeson Universal Company, Inc.
91 Technology Park Dr. Torrington, CT 06790
(860) 482-8283 www.borgeson.com

04/23/2010

