

1997-06 JEEP TJ PEDAL COVERS

FOR PART #'S: JP-180015-BL & JP-180016-BL

INSTALLATION INSTRUCCIONES **PAGE 1 OF 1**

TOOLS YOU'LL NEED FOR INSTALLATION


- Drill
- 3/16" drill bit
- Hammer,
- Drift
- Center punch
- Safety glasses
- Catch mat
- 2.5mm allen wrench
- 7mm hex wrench

WARNING!

Always wear gloves and protective eye-wear when operating a drill of any kind.

WARNING!

If any part of this installation seems beyond your level of installation experience, please seek the help of a certified professional.



INSTALLATION


For Brake & Clutch Pedals

1. Lay down a blanket or "catch mat" underneath your work area to collect metal shavings from drilling.
2. Remove factory rubber pedal covers.
3. Cover top surface of pedals with masking tape to prevent scratching
4. Place appropriate pedal cover centered on top of pedal on vehicle and use a punch to mark center point to drill
5. Remove billet cover and drill 3/16" holes where marked. Make sure to drill perpendicular to surface. Debur back side of pedal when done drilling.
6. Remove masking tape and place billet pedal cover onto pedals.
7. Secure using hardware provided.


For Fuel Pedal

1. Unbolt gas pedal assembly from fire wall. There are two nuts securing it about half way up the arm on the pedal.
2. Carefully push in tabs on backside of plastic clip securing throttle cable to fuel pedal assembly and remove cable from assembly.
3. Secure pedal assembly arm in a vice clamped as close as possible to the pin securing the pedal to the arm.
4. Using a hammer and drift, remove pivoting pin from assembly allowing removal of stock gas pedal. Make sure to note how the spring is positioned as it will be reused in the same orientation on new billet pedal.
5. Position billet pedal onto arm and start pin thru until teeth are starting to engage into billet pedal. At this point the pin should be partially thru the 1st thin tab on the pedal. Slide spring over exposed pin and then carefully hammer pin thru until teeth are fully seated into the arm itself. Make sure as you hammer the pin in that it properly lines up with the 2nd thin tab on billet arm. It is possible for it to mis-align and you will bend the tab if not careful with this installation.
6. Push throttle cable back into arm and bolt assembly back to the fire wall. Ensure proper function of pedal and throttle cable after installed specifically making sure that the cable does not hang up or get stuck on anything.

Enjoy your new pedals from Drake Off Road!



Automatic Pedal Covers



Manual Pedal covers