

JEEP AUTOMATIC SHIFT KNOB (TJ) INSTALLATION INSTRUCTIONS:



1. GRAB ORIGINAL SHIFT KNOB AND PULL IT OFF THE STOCK SHIFTER. IT WILL COME OFF USING EXTRA FORCE.
2. ROTATE SET SCREW TO DESIRED FINISHED POSITION AND TIGHTEN.



JP-180023-BL