

Hellwig PRODUCTS.com

559-734-7451 800-367-5480 FAX 559-734-7460

INSTALLATION INSTRUCTIONS


FRONT STABILIZER BAR

82-03 (2X4) S10-15 PICK UP

90-01 2WD 4-Door S10-15 BLAZER, JIMMY AND BRAVADA

Thank you for purchasing a quality Hellwig Product.

PLEASE READ THIS INSTRUCTION SHEET COMPLETELY BEFORE STARTING YOUR INSTALLATION





559-734-7451 800-367-5480 FAX 559-734-7460

TORQUE TABLE

BOLT SIZE: 3/8" = 20-30 ft. lbs. – 7/16" = 35-45 ft. lbs. – 1/2" = 50-70 ft. lbs. – 9/16" = 70-90 ft. lbs.

SAFETY: BEFORE STARTING YOUR INSTALLATION, BE SURE TO SET PARKING BRAKE AND CHOCK TIRES.

NOTE: TO EASE INSTALLATION AND TO PROPERLY ADJUST BAR, THE WEIGHT OF THE VEHICLE MUST BE ON THE SUSPENSION, AS IF DRIVING DOWN THE ROAD. DO NOT RAISE VEHICLE BY FRAME.

NOTE: THIS KIT INCLUDES LOCK NUTS WHICH REQUIRE TIGHTENING WITH A WRENCH AFTER BEING STARTED BY HAND.

1. If your vehicle has a factory installed front anti sway bar, remove the factory mounted sway bar and save mounting hardware for later use.
2. Lubricate and place the D-shaped poly bushings and U-plates on the sway bar as shown in photos 1 & 3. Place the sway bar onto the frame. Locate the threaded holes on the frame and start the bolts through the U-plates on the frame (**leave loose at this time to allow for adjustment later**).
NOTE: On some S-10 & S-15 models. It may be necessary to tap the existing frame holes. You will need an M10 x 1.5 tap. Tap the holes so that you can complete your sway bar installation.
3. Install the poly end link bushings and washers on the end links and attach the end links to the holes in the lower control arms as shown in photo two (2) . Tighten the lock nuts slightly just enough to where the bushings start to bulge.(**DO NOT OVER TIGHTEN**)
4. Tighten the frame bolts to manufacturer specification.
5. Bounce the vehicle and check for clearance on all undercarriage components. Turn the front wheel full lock left and then right. Make sure that at least (1/2") clearance is maintained between the sway bar and all steering linkage as well as the front tires. Be sure that all the nuts and bolts are securely fastened.
6. Recheck your installation, check for clearance to steering components, wires, exhaust pipes, fuel and brake lines etc.. After one week of driving recheck your installation and on a monthly basis thereafter.

ATTENTION INSTALLER: BE SURE THAT THE CUSTOMER RECEIVES THIS INSTRUCTION SHEET, ALL IMPORTANT NOTE CARDS AND THE WARRANTY FORM