

55366

FORD WINDSTAR

English

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

1/19/2012

1. Open the rear hatch and remove both taillight assemblies using a phillips head screwdriver (A).

2. Starting on the drivers side separate the top two taillight connectors from the back of the taillight assembly (B). Insert the T-connector end with the yellow wire in between the top separated connectors and insert the T-connector end with the brown/red wire in-between the middle separated connectors making sure the locking tabs are in place.

3. Route T-connector end with the green wire and the 4-flat down through the opening under the taillight assembly. Route the T-connector end with the green wire across to the passengers side along the back side of the bumper.

4. On the passengers side route the green wire up through the opening under the taillight. Repeat step 2 on the passengers side using the T-connector end with the green wire only separating the top connector.

5. On the drivers side Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

6. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

7. Route the black power wire from the battery as shown on the CME-PCL-INS sheet included.

8. Route the 4-flat wire to the center of the vehicle and secure using the cable ties provided

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

