

56131

KIA FORTE 5-DOOR

English

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

6/28/2013

1. Open the trunk. Remove all trunk floor covers (A).
2. Remove the cargo trays from the trunk floor (B,C).
3. Remove fasteners securing the rear scuff panel (D). Pull up and out to remove the scuff panel (E).

4. On the driver's side, remove the (4) fasteners securing the trim panel (F). Remove the plastic trim plate. To access the taillight connectors, pull out on the felt trunk liner (G). The connectors will be similar to those on the T-Connector harness. Separate the connectors taking care not to damage the locking tabs. Insert the T-Connector end with the yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

6. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure the eyelet of the white ground wire using the screw provided.

7. Locate a flat spot and adhere the black converter box to the frame of the vehicle using the double-sided tape provided.

8. Route the the T-Connector end with the green wire across to the passenger side behind the removed scuff panel. Repeat Step 4 on the passenger side using the T-Connector end with the green wire. Use the cable ties provided to secure wires to an existing wiring harness.

7. Route the 4-flat out from under the felt trunk liner and to the center of the vehicle when in use. Roll up and store in an out of the way location when not in use.
8. Reinstall all items removed during install.



INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813



