

56134 DODGE AVENGER CHRYSLER 200

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

3/25/2011

English

1. Open the trunk. Remove the rear scuff panel by removing the plastic fasteners holding it in place (A). On both sides of the trunk pull back on the felt trunk liner behind the taillights and locate two plastic wing nuts on each side (B). Remove the plastic wing nuts holding the taillights in place. Remove the taillights by pulling out.

2. On the driver side of the vehicle behind the taillight locate the vehicle's taillight wiring harness connectors (C). The connectors will be similar to those on the T-Connector harness. Separate the connectors taking care not to damage the locking tabs (D).

3. Behind the taillight remove the grommet that the wires run through from the inside of the trunk to the taillight. Make a small slit in the grommet to route the wires through. Route the T-Connector end with the yellow wire out through the slit in the grommet from the trunk out to the taillights. Insert the T-Connector end with yellow wires between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using ring terminal and screw provided.

5. Adhere the black converter box to the body panel inside the trunk behind the felt trunk liner of the vehicle using the double-sided tape provided.

6. Review instruction sheet CME-PCL-INS and route the black power wire from the battery to the converter as shown.

7. Route the T-Connector end with the green wire out from behind the felt trunk liner across to the passenger side behind the removed rear scuff panel. Repeat Step 2 on the passenger side using the T-Connector end with the green wire.

8. Route the 4-flat wire out from behind the felt trunk liner and to the center of the vehicle and out of the trunk when in use. When not in use roll up and store in a convenient out of the way location in the trunk. Secure any loose wires with the cable ties provided.

9. Reinstall all items removed during install.

INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813



