

56162

CHRYSLER TOWN & COUNTRY DODGE CALIBER DODGE GRANGE CARAVAN JEEP COMPASS JEEP PATRIOT

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

8/29/2012

English

1. DODGE CARAVAN/CHRYSLER TOWN & COUNTRY

Open the rear tailgate and remove the T-30 torx head screws that hold the taillights in place (A). Carefully pry the taillight housing rearward being careful not to break the locking tabs.

1. JEEP PATRIOT/COMPASS & DODGE DURANGO

Open the rear tailgate and remove the two clips that hold each taillight into place (B). Carefully pry the taillight housing rearward being careful not to break the locking tabs.

2. Behind the taillight housing locate the vehicles taillight wiring harness the connectors will be similar to those on the T-Connector (C). Disconnect the vehicle wiring harness from both taillight sockets (D). Insert the T-connector end with the yellow wire in-between the separated connectors on the drivers side being sure the locking tabs are in place (E).

3. Starting on the drivers side route the T-connector end with the green wire and the 4-Flat wire down through the opening between the vehicle bumper and the body. Under the vehicle route the green wire along the backside of the bumper to the passenger side and up through the opening on the passenger side. Repeat step 2 using the T-connector end with the green wire.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

5. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

6. Route the black power wire from the battery as shown on the CME-PCL-INS sheet included. Route the black wire through any rubber grommet in the trunk area if applicable to the black converter.

7. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

