



509 Hemlock St
Philipsburg, PA 16866
Ph- 814.343.6315 Fax- 814.343.6318
Installation Instructions
support@umiperformance.com
www.umiperformance.com

83-92 GM F-Body Tubular Steering Brace
(Will not fit 82 Models & 89 Turbo Trans Am)

1. Block rear wheels, jack up front of vehicle to good working height. Place jacks stands in a secure location.
2. Locate the front sway bar; loosen both ends links, one is located on the passenger side and the other on the driver's side. Do not remove them, loosening them will allow you to lower the sway bar.
3. Remove all (4) bolts from the front sway bar bushings. Lower the sway bar enough to insert steering brace.
4. The steering brace has the correct holes to be bolted under the front sway bar. Insert the brace and line the holes in the correct location. One side is intended for the driver's side and the other for the passenger side.
5. Swing the sway bar up into place. Use the OEM bolts removed and place the sway bar back into place. The bolts go through the sway bar and the steering brace. Loosely install all (4) bolts before tightening.
6. Tighten ends links and lower car to the ground.

Thank you for putting your trust in a UMI Performance Product!
www.umiperformance.com





Item # 2030

83-92 GM F-Body Steering Brace

UMI Performance Inc.
Made in Pennsylvania, USA