

3050, 3050F, 3051, 3051F

Position front springs as shown in the illustration below

The flat coil end should be positioned up while
the open coil end should be positioned in the Lower A-arm
Making sure you have the open coil end clocked correctly

Disregard the orientation of the UMI Sticker.

Stickers are installed by the spring manufacturer in no particular orientation and could be upside down when installed properly



If your car's front end seems to be sitting too high, check these items.

1. Be sure the lower control arm bucket is cleaned and free of dirt, mud, and rust.
2. Be sure the spring is sitting correctly in the lower A-arm. The open end of the coil should be
3. Be sure the spring is installed up inside the frame fingers correctly (see figure below). The figure on the left shows a correct installation. The fingers are all on the inside of the spring coils. The figure on the right shows an incorrect installation. The spring is clearly caught up on the fingers of the spring perch.



Tech Tip: If your spring is easily getting caught on the fingers of the spring perch, use a crowbar to bend them in a very small amount. This will also help ease the install of other springs in the future.

Item # 3050 - 3051

Front coil spring
UMI Performance Inc.
Made in Pennsylvania, USA