



Glass Setting Channel Installation Guidelines

1. Clean the lower edges of the window glass and the metal channels that the glass sets into. Be certain that the channels are free of rust and moisture. If channels need replacing, see Danchuk catalog for parts #1011-1022.
2. Your glass setting channel set has been prepared to fit many different applications. You will find two short lengths (front windows) and two long lengths (rear windows) in the set. Measure the lengths of your metal channels and cut your rubber setting channels accordingly, following the old adage: "measure twice, cut once."
3. When assembling the rubber and glass into the metal channels, use 3M weatherstrip adhesive (Danchuk #036) to fasten the parts together. The adhesive will also aid in preventing moisture from getting down into the metal channel.
4. If your original rubber channels had 'vee' cuts in the flaps, you may make identical cuts in your rubber. These 'vee' cuts are not necessary for correct operation of the window assembly.