



THROTTLE LINKAGE KIT P/N C3465

Parts List

- | | |
|---------------------------|------------------------|
| 1 1/4" R Hand Rod End | 2 1/4" Washer |
| 1 1/4" L Hand Rod End | 2 1/4" Locnut |
| 4 .34" Thick Carb Bushing | 1 1/4" x 1-1/2" HHCS |
| 3 .16" Thick Carb Bushing | 1 1/4" x 1-3/4" HHCS |
| 1 1/4" Jam Nut L Hand | 1 Carb Spring Bracket |
| 2 1/4" Jam Nut R Hand | 1 Throttle Linkage Rod |

Installation Instructions

1. Bolt one of the Rod Ends to the carburetor Linkage Rod after installing a Jam Nut on the Rod End.
2. Note that the Linkage Rod is threaded with a right hand thread on one end and with a left hand thread on the other end.
3. The Linkage Rod can be bent or cut to length but you may have to re-thread the cut end. Do this by first drilling the rod with a 7/32" drill bit then use a 1/4" x 28 tap.

NOTE: Cut the end with the right hand threads.

- Locate the point at which the throttle Linkage Rod will pass through the fire wall and drill a hole to ensure the rod will pass through without any binding.
4. Bolt the Throttle Linkage Rod to the carburetor using the 1-3/4" bolt, the Carb Spring Bracket and Carb Spring Bushings, and Washers supplied in this kit. Retain with a Loc-nut.
 5. Use the Bushings to space the Throttle Linkage Rod out from the Carburetor. Ensure there is no binding.
 6. Bolt the other end of the linkage rod to the gas pedal using the 1-1/2" Bolt supplied Bushings and Washers.

For Technical Assistance, Call Competition Eng. Tech Line
at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

COMPETITION ENGINEERING
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-5200 • Fax: (203) 453-6906

Visit Us At www.competitionengineering.com