

Spohn Performance, Inc.

494 E Lincoln Ave Myerstown, PA 17067

1-888-365-6064 www.spohn.net

Part #7-1208 – Rear Panhard Bar Polyurethane Bushings 1965-1970 Chevrolet B-Body

USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller or the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

INSTRUCTIONS

This SKU 7-1208 fits models with a factory panhard bar that has a 1.135" i.d. bushing on both ends. If your factory panhard bar has a 1.135" i.d. bushing on the chassis mount end and a larger 1.72" i.d. bushing on the rear axle housing mounting end of the panhard bar you will need to use our SKU 7-1207.

1. With the front wheels securely blocked, raise the rear of the car to an adequate working height, then support the chassis securely with jack stands leaving the differential slightly supported with the jack. Place the jack under the rear axle to support but do not lift.
2. Loosen and remove the nuts and bolts securing the factory rear panhard bar. Remove the factory rear panhard bar.
3. Remove the factory bushings from the panhard bar. Remove any old scale or rust build up from the inside of the factory panhard bar bushing eyelets. Using the supplied grease packets, apply a liberal amount of grease to the inside of the factory panhard bar bushing eyelets and to the new polyurethane bushings anywhere they will contact metal. Insert the new polyurethane bushings into each end of the factory panhard bar bushing eyelets. Apply grease to the outside of the bolt sleeves and slide them through the center bushing hole. Apply grease to the face of each bushing.
4. Install the panhard bar onto the car using the OEM bolts and make the nuts hand tight only at this time.
5. Safely lower the car to the ground. Tighten the mounting bolts to 30 ft./lbs.
6. DO NOT use petroleum-based grease on your poly bushings! Poly bushings must be lubricated with synthetic silicone based waterproof grease. These are the manufacturer's recommendations to prevent pre-mature bushing wear, and will keep things "squeak-free". You can order this grease from Spohn Performance using our Part #902.