

Spohn Performance, Inc.

494 E Lincoln Ave Myerstown, PA 17067

1-888-365-6064 www.spohn.net

Part# 930-FRONT – Front Sway Bar - 1970-1981 GM F-Body

USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller or the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

INSTRUCTIONS

1. Raise the front of the car to an adequate working height, then support the chassis securely with jack stands. The installation can be performed without removing the front wheels.
2. Look carefully at the current installation of the front sway bar and note the bar's properly installed orientation, etc.
3. Loosen all four of the factory front sway bar bushing bolts (two per side) leaving them engaged by a few threads to support the front sway bar.
4. Remove both of the front sway bar end links from each end of the front sway bar. These can be discarded.
5. Support and/or hold the front sway bar while removing the four front sway bar bushing bolts and then remove the front sway bar from the car.
6. Grease the inside bore of both of the supplied polyurethane front sway bar bushings using the supplied packets of Silicone® grease.
7. Install the polyurethane bushings onto our front sway bar. Orient the bushings so that the bushing's split seam will face the front of the vehicle when installed. Then install the metal shells over the polyurethane bushings.
8. Hold our front sway bar up into place and loosely install it into the car re-using the four factory front sway bar bushing mounting bolts. Do not fully tighten the bolts.
9. Loosely install the supplied polyurethane front sway bar end links to both ends of our front sway bar. Then install the other end of both of the end links to the front lower a-arms. This lower end can be fully tightened, keep the upper sway bar connected ends loose.
10. Push the front sway bar (bushings) as far forward as possible and then fully tighten all four of the front sway bar bushing bolts.
11. Safely lower the car to the ground.
12. With the car on the ground and the suspension loaded, using a 9/16" wrench, tighten the 3/8" Nylock® nut on the top of both of the front sway bar end links. Tighten the nuts until you see the bushings starting to deform, then STOP. Installation is complete.
13. DO NOT use petroleum-based grease on your polyurethane bushings! Poly bushings must be lubricated with synthetic silicone based waterproof grease. These are the manufacturer's recommendations to prevent pre-mature bushing wear, and will keep things "squeak-free". You can order this grease from Spohn Performance using our SKU 902.