

Spohn Performance, Inc.

494 E Lincoln Ave Myerstown, PA 17067

1-888-365-6064 www.spohn.net

Part# BS-7 Adjustable Bump-Steer Kit 1982-1992 GM F-Body with Pinto Manual Rack

USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller nor the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

INSTRUCTIONS

1. Lift the vehicle and support it with jack stands.
2. Loosen the top nut of the outer tie rod and strike the side of the spindle with a hammer until the old pin falls out of the spindle (or use a tie-rod puller).
3. Measure and record the distance of the rack end to the center of the outer tie rod end. This measurement will be used to set the length of the new assembly.
4. Thread the bump-steer adjuster on to the rack stud and set the center to center distance as measured in Step #3 above.
5. Insert the tapered end of the tie rod pin in to the spindle and cinch the top Nylock nut to hold it in place. Torque the top Nylock nut to 45 ft./lbs. and the bottom locking jam nut to 60 ft./lbs. (See Photo 1 and notes on Page 2).
6. The final choice of the rod end height location will be determined by the front end alignment shop.
7. Repeat Steps 2-5 on the opposite side of the vehicle.

Alignment: Now that you have your Spohn bump-steer kit installed, you will need to find a front end alignment shop that understands bump-steer, which is essentially a change in toe-in during suspension travel. To properly perform this alignment, the technician will put your vehicle on an alignment rack so the front wheels are on movable tables. He will then likely hook a come-along to the crossmember and one to the floor that will allow him to pull the vehicle throughout its suspension travel to measure the change in toe (bump-steer). He will then re-arrange the rod ends vertical positioning to minimize the problem.

In many cases, a subtle lowering of a car will not be enough to induce bump-steer, however, severe lowering, or the use of camber-caster plates will often cause the problem. By changing the angle of the tie rod assembly, done by extending or lowering the pin height, you can decrease your bump-steer to very small levels (less than factory).

The tapered spindle adapter does not fully seat into the spindle all the way down and against the hex. This is a common misconception that we'd like to clarify. The purpose of this kit is to LOWER the outer tie rod end. When seated into the spindle it will look like Photo 1 below.

Photo 1

