

Spohn Performance, Inc.

494 E Lincoln Ave Myerstown, PA 17067

1-888-365-6064 www.spohn.net

SKU FG-204 – Adjustable Rear Lower Control Arms – Polyurethane Bushings 1965-1974 Ford Galaxie

USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller nor the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

INSTRUCTIONS

1. Lift rear of vehicle and support by frame rails. DO NOT SUPPORT BY REAR END!
2. Use a jack and place it under rear axle to support, but do not lift.
3. Remove both rear lower control arm bolts and nuts and remove one control arm. The axle will shift slightly rearward. Only remove and install one control arm at a time.
4. Install the Spohn control arm using the jack to help position the rear axle housing properly. Make the bolts hand tight only at this time.
5. Repeat Steps 2-4 on the other side.
6. Safely lower the vehicle to the ground and tighten all bolts to 95 ft./lbs.
7. One end of the LCA adjuster is left hand threaded and the other end is right hand threaded. To adjust the length of your LCAs simply put a wrench on the hex in the center of the adjuster and turn the adjuster clockwise or counter-clockwise to lengthen or shorten the LCA. **Note:** LCAs are shipped jig set at stock length.
8. The polyurethane bushings come pre-lubed. DO NOT use petroleum-based grease on your poly bushings! Poly bushings must be lubricated with synthetic silicone based waterproof grease. These are the manufacturer's recommendations to prevent pre-mature bushing wear, and will keep things "squeak-free". You can order this grease from Spohn Performance using our Part# 902. Do not over grease the bushings! You only need a couple pumps of grease. Over greasing will cause the bushings to balloon from the hydraulic pressure inside of the sleeve and they will fail.
9. Jam nuts are known to work loose over time. To prevent this we recommend that after you have the LCAs set to your desired length you apply some REMOVABLE strength (Blue) Loctite to the adjuster threads and then tighten up the jam nuts on each end of the adjuster.