

Spohn Performance, Inc.
494 E Lincoln Ave Myerstown, PA 17067
1-888-365-6064 www.spohn.net

Part # D06-1500-FEL-2 – Front Sway Bar End Links – With 2"-3" Leveling Kit

2006-2018 Dodge Ram 1500 & 2019-2024 Ram 1500 Classic

USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller nor the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

INSTRUCTIONS

1. Block the rear tires of the vehicle so that the vehicle is stable and can't roll.
2. Remove the front end links from the front sway bar and the front lower control arms. The end links and all hardware may be discarded. It will be easier to do one side at a time.
3. Install the lower clevis stud through the front lower control arm end link mounting hole and thread on the supplied 1/2" top lock flange nut. Note that it may be necessary to clean up the mounting hole in the a-arm using a 1/2" drill bit. Hold the clevis with an adjustable wrench and make the lock nut snug tight only. Now clock the clevis so that is oriented as shown in Image 1 below. The open ends of the clevis must face left/right and the closed faces of the clevis face front/rear. While holding the correctly clocked clevis with an adjustable wrench tighten the 1/2" top lock flange nut to 110 ft./lbs.
4. Connect the other end of the end link to the front sway bar using the polyurethane bushings just like the factory set up. See Image 1 below. Make the 3/8" Nylock nut hand tight only at this time.
5. Repeat on the other side of the vehicle.
6. Safely lower the truck to the ground if it was raised.
7. With your suspension loaded and at ride height, tighten the top poly bushed end of both front end links. Hold the rod end with a wrench over the flats of the rod end. You want to tighten the top 3/8" Nylock nut until you see the bushings start to deform and then stop tightening.
8. Installation is complete.

Image 1 - Front End Link Installed

