

Spohn Performance, Inc.

494 E Lincoln Ave Myerstown, PA 17067

1-888-365-6064 www.spohn.net

Part# D94-13-FSB-32R – 32mm Greaseable Front Sway Bar Bushings **1994-2001 Dodge Ram 1500, 1994-2013 Dodge Ram 2500 & 1994-2012 Dodge Ram 3500**

USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller or the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

INSTRUCTIONS

1. Raise the front of the truck to an adequate working height, then support the chassis securely with jack stands. The installation can be performed without removing the front wheels.
2. Loosen all four of the factory front sway bar bushing bolts (two per side) leaving them engaged by a few threads to support the front sway bar.
3. Completely remove one sway bar bushing. It is easiest to replace one side at a time.
4. Grease the inside bore of both of the polyurethane front sway bar bushings using the supplied packets of Silicone® grease.
5. Thoroughly clean the sway bar of all grit and grime where the bushing will install. Then apply grease to the sway bar where the bushing will mount using the supplied packets of Silicone® grease.
6. Install the polyurethane bushing onto the sway bar. Orient the bushing so that the bushing's split seam will face the front of the truck when installed (See **Image 1** below).
7. Loosely install both factory front sway bar bushing mounting bolts. Do not fully tighten the bolts.
8. Repeat Steps 5-7 above on the other bushing.
9. Push the front sway bar (bushings) as far forward as possible and then fully tighten all four of the front sway bar bushing bolts.
10. Grease both bushings through the grease fittings. DO NOT use petroleum-based grease on your polyurethane bushings! Poly bushings must be lubricated with synthetic silicone based waterproof grease. These are the manufacturer's recommendations to prevent pre-mature bushing wear, and will keep things "squeak-free". You can order this grease from Spohn Performance using our SKU 902.
11. Safely lower the truck to the ground. Installation is complete.

Image 1

