

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 19416**

2005 Dodge Dakota 3.7L, 4.7L
Extended Cab, Quad Cab, 2WD/4WD



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. inlet pipe, muffler & tail pipe from the truck. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax inlet pipe **55255**. Insert the metal rod hanger into the rubber isolator on the chassis. Finger tighten the inlet clamp.
3. Install DynoMax Ultra Flo Welded muffler **17236**. **The muffler should be installed with the center connection as the inlet and with the muffler at approximately a 45° angle. The top of the muffler should tilt toward the RH (passenger side) frame. The outlet side connection should be at the bottom.** Finger tighten the inlet clamp. (NOTE: If equipped, reinstall the electrical grounding strap to one of the u-bolt clamp legs.)

4. Install DynoMax tail pipe **55256**. Insert the metal rod hangers into the two rubber isolators on the chassis. Finger tighten the outlet clamp.
5. Beginning at the inlet end, align the system and fully tighten all the clamps.
6. Please see system diagram on back page of these instructions.

KIT CONTAINS:

- (1) 17236 MUFFLER
- (1) 55255 INLET PIPE
- (1) 55256 TAIL PIPE
- (3) 2½" CLAMPS
- (1) 701407 INSTRUCTION SHEET

19416 SYSTEM DIAGRAM

