

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 19418**

1998-02 Chevrolet Camaro / Pontiac Firebird, Trans Am
5.7L V8 Dual Exhaust



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the old exhaust system from the vehicle. Use WD-40, or a similar lubricant, to aid in removing the rod hangers from the rubber isolators.
2. Install DynoMax front bullet resonator pipe **54354**. Finger tighten the front 2 $\frac{3}{4}$ " clamp.
3. Install DynoMax over-axle pipe **53061**. Insert the rod hanger assembly into the rubber isolator above the axle on the right hand side. Finger tighten the 3" clamp on the connection to the front bullet resonator pipe.
4. Install muffler eliminator y-pipe **53365**. **Please check the diagram on the back page of these instructions to view the correct positioning of this pipe.** Finger tighten the 3" clamp that connects to pipe 53061.

5. Install LH tail pipe **53063**. Insert the rod hanger into the rubber isolator. Finger tighten the 3" clamp that connects to 53365.
6. Install RH tail pipe **53062**. Finger tighten the 3" clamp that connects to 53365 on this side.
7. Beginning at the inlet end, align all components and tighten all the clamps. Please see system diagram on back page of these instructions.

KIT CONTAINS:

- (1) 54354 BULLET PIPE
- (1) 53061 AXLE PIPE
- (1) 53365 Y-PIPE
- (1) 53062 TAIL PIPE
- (1) 53063 TAIL PIPE
- (1) 2 $\frac{3}{4}$ " CLAMP
- (4) 3" CLAMPS
- (1) 701458 INSTRUCTION SHEET

19418 SYSTEM DIAGRAM

