

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 19433**
2007 Hummer H2 6.0L V8



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. inlet pipe/muffler/tail pipe assembly from vehicle. Lubricate the rubber isolators with WD-40, or a similar lubricant, to aid in removal of the metal rod hangers.
2. Install DynoMax front exhaust pipe **53415**. Insert the metal rod hanger into the rubber isolator on the chassis. Finger tighten the nuts on the inlet flange.
3. Install DynoMax Ultra Flo Welded oval muffler **17557**. **The inlet or outlet end designation is stamped on the shell of the muffler.** The muffler should install at approximately a 45° angle with the top of the muffler tilted toward the RH (passenger) side and the inlet connection at the top. Finger tighten the 4" inlet clamp at the connection to the front pipe.
4. Install DynoMax tail pipe **54411**. Insert the metal rod hangers into the two rubber isolators on the chassis. Finger tighten the 4" clamp to the muffler outlet.

5. Beginning at the inlet end, align the exhaust system components and fully tighten all the clamps

6. Please see system diagram on back page of these instructions.

KIT CONTAINS:

- (1) 17557 MUFFLER
- (1) 53415 INLET PIPE
- (1) 54411 TAIL PIPE
- (2) 4" CLAMPS
- (1) 702527 INSTRUCTION SHEET

19433 SYSTEM DIAGRAM

