

INSTALLATION INSTRUCTIONS FOR DYNOMAX DUAL KIT: 19472

2007-04 Chevrolet/GMC Colorado/Canyon, Isuzu I-Series
2.8L, 2.9L, 3.5L, 3.7L Crew Cab, Ext. Cab Short Bed
THE SPARE TIRE MUST BE REMOVED FROM UNDER THE
PICK-UP BED AND PERMANENTLY RELOCATED TO INSTALL
THIS DUAL SYSTEM



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. exhaust system from behind the converter assembly. Use WD-40, or similar lubricant, to aid in remove the metal rod hangers from the the rubber isolators.
2. Install DynoMax front pipe **53577** to the outlet of the OE converter assembly. Insert the rod hanger into the rubber isolator on the passenger side frame. Finger tighten the inlet flange fasteners.
3. Install DynoMax muffler **17758**. The muffler should lay flat when properly positioned. Finger tighten the 2½" muffler inlet clamp.
4. Install DynoMax RH extension pipe **53579**. Finger tighten the 2½" clamp at the muffler outlet connection.
5. Slip a 2½" band clamp over the inlet of RH tail pipe **53580** and install. Please reference the system diagram. Temporarily support the 53580 tail pipe.
6. Install DynoMax LH extension pipe **53578**. Slip the rod hanger into the OE rubber isolator. Finger tighten the 2½" clamp at the muffler outlet connection.

7. Slip a 2½" band clamp over the inlet of LH tail pipe **54570**. Temporarily support the tail pipe.
8. Install both adjustable length tail pipe rod hangers from the **36447** hardware kit. These will position over the rod hangers on 53580 & 54570 tail pipes. Each rod hanger can be adjusted for proper drop down length. Install all washers and tighten the hex nuts. These rod hangers connect to the tail pipes with the rubber isolators included in the kit.
9. Beginning at the inlet end, align the system components and fully tighten all the clamps. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 17758 MUFFLER
- (1) 53577 INT. PIPE
- (1) 53579 EXT. PIPE
- (1) 53578 EXT. PIPE
- (1) 53580 TAIL PIPE
- (1) 54570 TAIL PIPE
- (1) 36447 HARDWARE KIT
- (2) 2½" BAND CLAMP
- (3) 2½" SADDLE CLAMPS
- (1) 705337 INSTRUCTION SHEET

19472 SYSTEM DIAGRAM

