

Installation Instructions for Dynomax VT Muffler Kit **38311**

2007-1999 Chevrolet Silverado 1500/2500 4.3L, 4.8L, 5.3L ext cab, short bed 143.5" (<8600 GVW) ('07 Classic models only)

2007-1999 GMC Sierra 1500/2500 4.3L, 4.8L, 5.3L ext cab, short bed 143.5" (<8600 GVW) ('07 Classic models only)

Danger Warning: Should the purchaser decide to install this exhaust product at home, be warned that light duty truck "bumper" jacks are intended for emergency use only. The use of frame contact jack stands is highly recommended to minimize accidental dropping of a vehicle during the installation process. Failure to heed this warning could result in severe injury or death.

Note: Please read all instructions before beginning the installation.

1. Remove the OE muffler assembly. Lubricate the rubber insulators with WD-40 or a similar product to aid in removing the rod brackets.
2. Install intermediate pipe **55512**. Insert the rod hanger into the rubber isolator hanger. Slightly tighten the inlet fasteners.
3. Install Dynomax VT muffler **17962**. The outlet end of the muffler is stamped on the shell.
4. Install tail pipe **55513**. Insert the required rod hangers into the rubber isolator hangers.
5. Beginning at the inlet end, position all components and tighten all clamps and fasteners.
6. Start the engine and check for leaks or rattles. Adjust as required. PLEASE SEE THE SYSTEM DIAGRAM ON THE BACK PAGE.

Kit contains:

- (1) 17962 muffler
- (1) 55512 pipe
- (1) 55513 pipe
- (2) 3" clamp
- (1) instruction sheet

Form: 711414
02/2011