

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX VT MUFFLER KIT: 38497**

2013-09 Chevrolet Silverado 1500 / GMC Sierra 1500
4.8L, 5.3L V8, Regular Cab, Standard Bed,
133" W.B., 2 / 4 W.D., Single Exhaust



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Please read all instructions before starting any work.

1. Remove the OE inlet pipe/muffler/tail pipe assembly from the vehicle. Lubricate the rubber isolators with WD-40 or a similar product to aid in removal of the metal rod hangers from the rubber isolators.
2. Install DynoMax front exhaust pipe **54720**. Insert the metal rod hanger into the rubber isolator on the chassis. Slightly tighten the reusable OE clamp on the front exhaust pipe.
3. Install DynoMax VT muffler **17949**. The muffler should lie flat and install with the center connections as the inlet and with side outlet connection toward the passenger side. Slightly tighten the 3" inlet clamp at the connection to the front pipe.
4. Install outlet extension pipe **51061**. This pipe may require to be shortened. Test fit with tail pipe.

5. Install DynoMax tail pipe **54704**. Insert the (3) metal rod hangers into the rubber isolators on the chassis. .
6. Install DynoMax the **36474** tip with the supplied band clamp.
7. Beginning at the inlet end, align all the exhaust components and fully tighten all clamps.
8. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 17949 VT MUFFLER
- (1) 54720 INLET PIPE
- (1) 51061 EXTENSION PIPE
- (1) 54704 TAIL PIPE
- (1) 36474 TIP w/3" BAND CLAMP
- (3) 3" BAND CLAMPS
- (1) 711400 INSTRUCTION SHEET

38497 SYSTEM DIAGRAM

