

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX VT MUFFLER KIT: 38515**

2012 Jeep Wrangler 3.6L, 2 Door



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Please read all instructions before beginning the installation.

1. Remove the old exhaust from behind the catalytic converters and y-pipe. Lubricate the rubber isolators with WD-40, or a similar product to aid removal of the metal rod hangers.
2. Install the DynoMax front intermediate pipe **53840** and rear intermediate pipe **54753**. Insert the rod hanger into the rubber isolators. Slightly tighten the 2½" clamp.
3. Install DynoMax VT muffler **17959**. The driver side OE rod hanger at the front of the muffler is not used for this DynoMax system. Slightly tighten the 2½" clamp that connects this muffler to the outlet of rear intermediate pipe.

4. Install tail pipe **51079** and SS tip **36486**. Be sure to insert the metal rod hanger into the rubber isolator. See system diagram on the back page of these instructions.
5. Beginning at the inlet end, align system components and fully tighten all the clamps.

KIT CONTAINS:

- (1) 17959 DYNOMAX VT MUFFLER
- (1) 53840 FRONT INTERMEDIATE PIPE
- (1) 54753 REAR INTERMEDIATE PIPE
- (1) 51079 TAIL PIPE
- (1) 36486 SS TIP w/2½" BAND CLAMP
- (4) 36438 2½" BAND CLAMPS
- (1) 712417 INSTRUCTION SHEET

38515 SYSTEM DIAGRAM

