

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX MUFFLER KIT: 38526**

2012-09 Toyota Tundra CrewMax, Double Cab,
Regular Cab – 145.7" WB w/5.7L



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Please read all instructions before beginning the installation.

1. Remove the existing inlet pipe/muffler/tail pipe assembly from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax R.H. front pipe **53850** and L.H. front pipe **52510**. Reuse the OE gaskets or install new gasket **31512** on both pipes. Slightly tighten the inlet connection on both pipes.
3. Install DynoMax VT muffler **17964**. The muffler should lie flat when installed. Slightly tighten the 2½" inlet clamps.
4. Install DynoMax over-axle pipe **54805**. Insert the metal rod hanger into the rubber isolator on the chassis. Slightly tighten the 3" clamp to the muffler outlet.
5. Install DynoMax tail pipe **53866**. Slightly tighten the 3" clamp to the over-axle pipe.
6. Install DynoMax SS tip **36505** using the included 3" band clamp.

7. Beginning at the inlet end, align the exhaust system components and fully tighten all the clamps.
8. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 53850 INLET PIPE
- (1) 52510 INLET PIPE
- (1) 17964 VT MUFFLER
- (1) 54805 OVER-AXLE PIPE
- (1) 53866 TAIL PIPE
- (1) 36505 SS TIP w/3" CLAMP
- (2) 31512 GASKET
- (2) 2½" BAND CLAMP
- (2) 3" BAND CLAMP
- (1) INSTRUCTION SHEET

38526 SYSTEM DIAGRAM

