

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX MUFFLER KIT: 38527**

2010-05 Dodge Charger & Magnum R/T, Chrysler 300C w/5.7L



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN BUMPER JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS, IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT, IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Please read all instructions before beginning the installation.

1. Remove the existing exhaust system from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax front exhaust x-pipe **53716**. Slightly tighten the inlet clamps.
3. Install DynoMax VT muffler **17960**, right hand and left hand. Slightly tighten the 3" clamps that connect the mufflers to the x-pipe.
4. Install DynoMax R.H. tail pipe **55496** and L.H. tail pipe **55495**. Insert the metal rod hangers into the rubber isolators on the chassis. Use 3" clamps to connect the tail pipes to the muffler outlets.
5. Install DynoMax 304SS polished tips **36472**, right hand and left hand.

6. Beginning at the inlet end, align all the parts and fully tighten all the clamps.
7. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 53716 FRONT X PIPE
- (2) 17960 DYNOMAX **VT** MUFFLER
- (1) 55495 TAIL PIPE
- (1) 55496 TAIL PIPE
- (2) 36472 TIP w/2¾" CLAMP
- (2) 2½" BAND CLAMP
- (4) 3" BAND CLAMP
- (1) INSTRUCTION SHEET

38527 SYSTEM DIAGRAM

