

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX MUFFLER KIT: 39524**
2015-12 Jeep Wrangler 3.6L
Cat-Back Single Exhaust System



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME. BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Please read all instructions before beginning the installation.

1. Remove the O.E. exhaust from behind the catalytic converters. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax intermediate pipe **52515**. Insert the rod hanger into the rubber isolator. Slightly tighten the 2½" on the inlet end. Please see the system diagram.
3. Install DynoMax muffler **17263**. Slightly tighten the 2½" clamp that connects this muffler to the outlet of the 52515 front pipe.
4. Install tail pipe **55428**. Be sure to insert the metal rod hangers into the rubber isolators. Slightly tighten the 2½" clamp that connects the tail pipe to the muffler outlet.

5. Install DynoMax tip **36484** on the outlet of the tail pipe.
6. Beginning at the inlet end, align system components and fully tighten all clamps.

KIT CONTAINS:

- (1) 17263 MUFFLER
- (1) 52515 INTERMEDIATE PIPE
- (1) 55428 TAIL PIPE
- (1) 36484 TIP w/2½" BAND CLAMP
- (3) 2½" BAND CLAMPS
- (1) 713035 INSTRUCTION SHEET

39524 SYSTEM DIAGRAM

