

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX VT MUFFLER PROFESSIONAL
INSTALLERS DUAL KIT: 88346**

2010-04 Chevrolet / GMC Pickups
2008-04 Dodge Ram Pickups
2010-04 Ford F-Series Pickups



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Please read all instructions before starting any work.

1. Remove the OE muffler/tail pipe assembly. Use WD-40 or a similar product to lubricate and help remove the metal rod hangers from the rubber isolators.
2. Install DynoMax VT muffler **17963**. Install hangers as required.
3. Install RH over-axle pipe **64346** and LH over-axle pipe **64347**. Fabricate and/or install hangers as required.

4. The rear tail pipes **65067** & **65068** will require modification for final installation. These pipes can be bent and cut-off for side exit or cut-off for rear exit. Fabricate and/or install hangers as required.
5. Install SS tips **36486** onto both tail pipes using the band clamps provided.

KIT CONTAINS:

- (1) 17963 VT MUFFLER
- (1) 64346 PIPE
- (1) 64347 PIPE
- (1) 65067 PIPE
- (1) 65068 PIPE
- (2) 36486 SS TIPS w/2½" BAND CLAMPS
- (4) 2½" BAND CLAMPS
- (1) 3" BAND CLAMP
- (1) 711408 INSTRUCTION SHEET

88346 SYSTEM DIAGRAM

