

Mopar[®] ACCESSORIES

82206373

82206374

82206375

CONTENTS

- (2) front visors
- (2) rear visors - if applicable
- (2) or (4) alcohol pads - depending on application
- (1) instruction sheet

IMPORTANT: Read all instructions carefully before beginning installation. The ideal installation temperature is between 65°-110°F (18°- 43°C). A “dry-run” trial fit is recommended to insure proper positioning.

STEP 1: Clean the painted door frame where the visor will mount with an alcohol pad. See **FIGURE 1**

STEP 2: Remove the tape liner from the rear end flange. Expose approximately 2” of tape from each end of the lateral flange by peeling back liner. See **FIGURE 2**

STEP 3: Align the visor with the previously cleaned door frame. After properly positioning the visor onto the door frame, remove the tape liner to expose the remaining tape. Press on all tape flanges to ensure proper adhesion of the tape to the surface.

If applicable, proceed to next step

STEP 4: Clean the painted door frame where the visor will mount with an alcohol pad. See **FIGURE 3**

STEP 2: Remove the tape liner from the front and rear end flanges. Expose approximately 2” of tape from the lateral flange by peeling back liner. See **FIGURE 4**

STEP 3: Align the visor with the previously cleaned door frame. After properly positioning the visor onto the door frame, remove the tape liner to expose the remaining tape. Press on all tape flanges to ensure proper adhesion of the tape to the surface.

