

Dee Zee ABS Bedcap Installation Instruction

- 1. The temperature must be between 70 degrees and 100 degrees (Fahrenheit) or 20 degrees to 38 degrees (Celsius) before beginning this installation.**
- 2. Clean the surface of the truck bed rail of any dirt before proceeding with this installation. Now use the enclosed alcohol pads to clean the surface of any further surface contaminants to promote better adhesion to the truck bed rail surface.**
- 3. Place the ABS bedcap on the truck bed rail to ensure that it fits prior to peeling the backing off of the tape.**
- 4. Peel the backing off of the tape on the ABS bedcap.**
- 5. Place the ABS bedcap up to the truck bed rail and place it in the desired position and then press firmly into place for atleast 20 to 30 seconds to ensure proper adhesion to the truck bed rail surface.**
- 6. It is our recommendation that the ABS bedcaps are allowed to sit on the vehicle for 24-48 hours at 70 degrees and 100 degrees (Fahrenheit) or 20 degrees to 38 degrees (Celsius) to allow better adhesion to the vehicle prior to the vehicle moving on any roadways. The ultimate bond strength of the tape will be reached over this period of time.**

Dee Zee ABS Bedcap Installation Instruction

- 1. The temperature must be between 70 degrees and 100 degrees (Fahrenheit) or 20 degrees to 38 degrees (Celsius) before beginning this installation.**
- 2. Clean the surface of the truck bed rail of any dirt before proceeding with this installation. Now use the enclosed alcohol pads to clean the surface of any further surface contaminants to promote better adhesion to the truck bed rail surface.**
- 3. Place the ABS bedcap on the truck bed rail to ensure that it fits prior to peeling the backing off of the tape.**
- 4. Peel the backing off of the tape on the ABS bedcap.**
- 5. Place the ABS bedcap up to the truck bed rail and place it in the desired position and then press firmly into place for atleast 20 to 30 seconds to ensure proper adhesion to the truck bed rail surface.**
- 6. It is our recommendation that the ABS bedcaps are allowed to sit on the vehicle for 24-48 hours at 70 degrees and 100 degrees (Fahrenheit) or 20 degrees to 38 degrees (Celsius) to allow better adhesion to the vehicle prior to the vehicle moving on any roadways. The ultimate bond strength of the tape will be reached over this period of time.**