

D-JP-190049UNIVERSAL PICATINNY
RAIL MIRROR**TOOLS REQUIRED**

- 12mm socket
- 1/4" or 1/2" ratchet
- 3mm Allen head socket or Allen wrench
- Safety Glasses

SKILL LEVEL

- Novice/Intermediate
 - 1(you) person
- Little skill level required, you can easily install it by yourself.

TIME REQUIRED

- 15 TO 20 MIN
- Time to install these mirrors should only take 15 to 20 minutes.

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit requires knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle.

• *Always wear eye protection when operating power tools.* •

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information:

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



INSTALLATION MANUAL

STEP 1: Unboxing your Picatinny Rail Mirrors. This kit comes with both driver and passenger mirrors and 2 picatinny mounts

Note: *Before you start* – This product is not compatible with OEM doors when mounting on the A-pillar rail system

STEP 2: Mirrors included are 1 flat mirror and 1 convex mirror. Typically the convex mirror goes on the passenger side.

STEP 3: The 2 picatinny mounts are side specific. They will mount to the rail with the logo reading properly, and with the set screw facing the back of the vehicle. Not upside down and angled forward.

STEP 4: Steps 4 through 6 can be done in either order. Which ever you feel is best for you. In our example we loosen the set screw using a 3mm Allen head socket or wrench so there is sufficient play between the parts. Then slide the mount on the rail from top or bottom to the desired locatoin.



INSTALLATION **MANUAL**

STEP 5B: If there are already products on the rail, another quick way to mount to the rail is - Again with the mount loosened generously, clip the front of the mount to rail and slip the back of the mount over until the grooves line up. Then just tighten the set screw.



STEP 6: Using the 3mm Allen head socket or wrench tighten the set screw to the rail.



STEP 7: Holding the Mirror to the mount - tighten the 12mm bolt into the mirror shaft.



STEP 8: **You're done!** Make final viewing adjustments to the mirror assembly. Tighten down all hardware.

Enjoy your Picatinny rail Mirrors.

