

INSTALLATION INSTRUCTIONS

INSTALLATION INSTRUCTIONS

- 1 • Position HOOD PRODUCT centrally over hood
 - Note two holes corresponding to center slots in HOOD PRODUCT, these center holes may be being covered by existing rubber hood stops or pins.
 - Also note the slot near the outer wing tags
- 2 • Remove previously noted rubber hood stops and the section of rubber trim that may run along the hood lip edge on certain models.
 - Retain rubber hood stops in vehicle glove box.
- 3 • Insert plastic screw plugs into two center holes previously noted corresponding to center slots.

NOTE: Due to variance of hole size in hood, a pair of 7mm screwplugs (grey) and a pair of 8mm screwplugs (black) are supplied. Trial each pair, insert best fitting screwplugs into holes.
- 4 • Trial fit the metal clip into the outer noted slots as shown. The hook section of clip locates into the slots in the hood.
 - Note the areas of tape in contact with the hood.
 - Clean these areas with the alcohol wipe provided, wipe away any residue with a dry clean cloth.
 - The correct temperature to install the double sided tape is between 105 Fahrenheit and 70 Fahrenheit.
- 5 • Peel tape liner off clip and re-fit to hood.
 - Install HOOD PRODUCT ensuring the raised boss of screw plugs locate within center slots of HOOD PRODUCT tags and wing tag slots located over stud in metal clip. Secure onto hood using flange screws, washers and nuts provided.
- 6 • On vehicle models that have the rubber hood trim re-attach trim to vehicle where applicable, adhering trim to HOOD PRODUCT tag.

• Note: On vehicles with limited hood to grill clearance, it may be necessary to adjust hood bump stops (refer to owners manual).

To Remove: Reverse above procedure. Use Solignum. Use mild detergent and water solution. (Do NOT use Solignum). Avoid the use of automatic "Black Shine" car waxes. When drying the hood, do NOT put on SuperGloss.

MADE IN AUSTRALIA

