

# INSTALLATION INSTRUCTIONS

## INSTALLATION INSTRUCTIONS

- 1
  - Position **HOOD PRODUCT** centrally on hood. Note the slots in the underside of hood corresponding to the slots in **HOOD PRODUCT** tags.
  - Remove **HOOD PRODUCT**.
- 2
  - Locate screw plugs into previously noted slots in hood.
- 3
  - Refit **HOOD PRODUCT**.
  - Secure the **HOOD PRODUCT** using screws provided.
  - **DO NOT OVERTIGHTEN SCREWS.**

**To Remove:** Reverse above procedure.

**To Clean:** Use mild detergent and water solution. (Do **NOT** use solvents).

Avoid the use of automatic "Brush Style" car washes. When closing the hood, do **NOT** pull on **HOOD PRODUCT**.

