

INSTALLATION INSTRUCTIONS



- Do not use power tools to install this product.
- No battery operated screw guns.
- The use of power tools during installation may void the product warranty.
- Do not overtighten.

MADE IN AUSTRALIA

INSTALLATION INSTRUCTIONS

1. Clean the vehicle before installation of the Hood Protector.
2. Open the hood. Note the two (2) rubber spacers, as shown in Diagram 2.
3. Remove the rubber spacers by turning 90° in either direction. Retain spacers for possible re-installation.
4. Trial-fit the Hood Protector. Note the holes in the hood that correspond with the slots in the Hood Protector tabs. Remove Hood Protector.
5. Install the two (2) round-headed screw plugs into the now vacant slots, as shown.
6. Install the square headed screw plugs into the three (3) vacant holes corresponding to the slots in the Hood Protector tabs, as shown.
7. Screw the double-headed screws into the square screw plugs. If required, lock the screw plugs in place using a 9/16" wrench. Ensure the double-headed screw is fully threaded into the screw plug. Ensure the wrench does not damage the hoods paintwork.
8. Fit the Hood Protector over the double-threaded screws. Attach the Hood Protector to the three (3) double-threaded screws with the knurl nuts and gray rubber washers. Complete installation by attaching to the remaining screwplugs with the screws and black fiber washers, as shown.
DO NOT OVERTIGHTEN!

To Clean: Use mild detergent and water solution (Do **NOT** use solvents). Avoid the use of automatic "Brush Style" car washes. When closing the hood, do **NOT** pull on Hood Protector.

