

INSTALLATION INSTRUCTIONS

INSTALLATION INSTRUCTIONS

- 1 • Position **AERO WRAP** centrally over hood.
 - Note two holes corresponding to center slots in **AERO WRAP**, these center holes may be being covered by existing rubber hood stops or trims.
 - Also note the slot near the outer wing tags.
- 2 • Remove previously noted rubber hood stops and the section of rubber trim that may run along the hood lip edge on certain models.
 - Retain rubber hood stops in vehicle glove box.
- 3 • Insert plastic screw plugs into two center holes previously noted corresponding to center slots.

NOTE: Due to variance of hole size in hood, a pair of 7mm screwplugs (grey) and a pair of 8mm screwplugs (black) are supplied. Trial each pair, insert best fitting screwplugs into holes.
- 4 • Trial fit the metal clip into the outer noted slots as shown. The hook section of clip locates into the slots in the hood.
 - Note the areas of tape in contact with the hood.
 - Clean these areas with the alcohol wipe provided, wipe away any residue with a dry clean cloth.
 - The correct temperature to install the double side tape is between 105 Fahrenheit and 70 Fahrenheit.
- 5 • Peel tape liner off clip and refit to hood.
 - Install **AERO WRAP** ensuring the raised boss of screw plugs locate within center slots of **AERO WRAP** tags and wing tag slots located over stud in metal clip. Secure onto hood using fixing screws, washers and nuts provided.
 - On vehicle models that have the rubber hood trim, re-attach trim to vehicle, where applicable, adhering trim to **AERO WRAP** tag.
- 6 • Note: On vehicles with limited hood to grill clearance it may be necessary to adjust hood bump stops. (Refer to owners manual).

To Remove: Reverse above procedure.
To Clean: Use mild detergent and water solution. (Do NOT use solvents).
Avoid the use of automatic "Brush Style" car washes. When closing the hood, do NOT pull on **AERO WRAP**.

MADE IN AUSTRALIA

