

FRONT DOOR INSTALLATION



INSTALLATION INSTRUCTIONS

TM

SLIMLINE WINDOWVISOR



MADE IN USA

INSTALLATION INSTRUCTIONS

- 1• Clean and dry upper door frame. Trial fit **WINDOWVISOR** onto door frame. Note tape attachment areas. **DO NOT REMOVE TAPE LINER.**
- 2• Prepare tape attachment area with alcohol wipes provided. Remove residue with a clean, dry cloth. Wipe dry with a clean cloth.
- 3• Peel back approx. 50mm (2") of tape liner from EACH of the three tape sections and fold at 45° to outside of **WINDOWVISOR**. **DO NOT TOUCH EXPOSED SURFACE OF TAPE.**
- 4• Position **WINDOWVISOR** on door frame with the bottom step positioned over the mirror support. Apply light pressure to exposed tape areas.
- 5• Peel off remaining tape liner by pulling on exposed ends of liner, and apply firm pressure around attachment areas.
- 6• Using a clean, soft cloth rub down firmly around attachment area 4 times to ensure maximum adhesion.

IMPORTANT: Before fitting product, read instruction fully. Reverse the above procedure to remove this product.

TO CLEAN: Use mild detergent and water solution. (Do NOT use solvents). Avoid the use of automatic "Brush Style" car washes.

