

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



PRO-KIT- #2820.140

Chrysler, Neon, 4-door, (Incl. R/T & ACR Models)

2000-2004

Dodge, Neon, 4-door, (Incl. R/T & ACR & SRT4 Models)

2000-2004

Plymouth, Neon, 4-door, (Incl. R/T & ACR Models)

2000-2004

Kit Contents	Description	Part Number	Qty
	Front Spring	2820.001	2
	Rear Spring	2820.102	2
	Information Kit	EPAK	1
	Instructions	2820.140INST	1

NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands.
- **PRO-KIT** springs are marked with a .001, for Front and .002, for the Rear.
- **PRO-KIT** springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **PRO-KIT** Springs.
- **After** installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

ALIGNMENT:

After installation, it will be necessary to perform a full vehicle alignment. **Eibach** offers the following alignment kits for this vehicle.

Part #: 5.83450K

Front/ Rear: Rear

Camber Adjustment: +/-1.0°

Part #: 5.81250K

Front/ Rear: Front

Camber Adjustment: +/- 1.75°

Bump Stop Trimming Instructions

Typical Bump-Stop
(Bump-Stop from your vehicle may have different shape)

