

Installation Instructions



Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

Pro-Truck – #38152.520

CHEVROLET – Avalanche, 2WD/4WD exc. Autoride, 2007-2011

CHEVROLET – Suburban, ½ ton, 2WD/4WD exc. Autoride, 2007-2011

CHEVROLET – Tahoe, 2WD/4WD exc. Autoride & Hybrid, 2007-2011

GMC – Yukon, 2WD/4WD, exc. Autoride, 2007-2011

GMC – Yukon XL, exc. Autoride, 2007-2011

Please Note: This kit was designed for vehicles with stock wheels and tires. Installation of low profile tires and larger wheels may affect the ride quality. Performance dampers are recommended.

Kit Contents	Description	Part Number	Qty
	Front Springs	38107.101	2
	Front Bumpstop	BS770015	2
	Information Kit	EPAK	1
	Instructions	38152.520INST	1

NOTES: Read All Instructions Before Beginning Installation

- **Installation of a PRO-Truck Spring** set should only be performed by a qualified mechanic experienced in the installation and removal of suspension springs.
- **Use of a hoist** is highly recommended and will substantially reduce installation time.
- **Never work on or under a vehicle** unless it is properly supported by safety stands and wheels are blocked.
- **PRO-Truck** Springs are marked with 01 and 02 (located at the end of the part number) designating front and rear spring respectively.
- **PRO-Truck** Springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **PRO-Truck** Springs.
- **After installation**, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

ALIGNMENT:

After installation, it will be necessary to perform a full vehicle alignment to ensure proper tire wear and performance.

Front Bump Stop
Replace OE bump stop with
Eibach p/n BS770015.

