

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



PRO-KIT- # 38136.140

2008 Cadillac, CTS, V6, Exc. AWD

(Vehicles with FE3 Sport Suspension please see note below)

Kit Contents	Description	Part Number	Qty
	Front Spring	38136.001	2
	Rear Spring	38136.002	2
	Information Kit	EPAK	1
	Instructions	38136.140INST	1

NOTES: Read All Instructions Before Beginning Installation

- Installation of a **PRO-KIT** Spring set should only be performed by a qualified mechanic experienced in the installation and removal of suspension springs.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- **Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.**
- **PRO-KIT** Springs are marked with 01 and 02 (located at the end of the part number) designating front and rear spring respectively.
- **PRO-KIT** Springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **PRO-KIT** Springs.
- **After** installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe.
 - Tire and/or wheel fender clearance.
 - Brake line clearance and attachments.
 - Brake anti-locking and anti-skid system sensors.
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.
- **For MacPherson Strut** type front suspension, it is important to mark the orientation of the upper perch with respect to the lower perch before disassembly. This orientation must remain the same with the installation of the Pro Kit springs. Noise may result if this procedure is not performed correctly.

Alignment:

After installation, it will be necessary to perform a full vehicle alignment.

Bump Stop Instructions

FRONT: No front bump stop modifications required.

REAR: No front bump stop modifications required.

NOTE: Models with FE3 Sport Suspension,

If your CTS is equipped with the FE3 Sport suspension, you will need to replace your OE self leveling rear shocks with the non self leveling rear shocks from the FE1 Soft Ride Suspension - (OE P/N 15219474 – right side, 15219473 – left side), or the FE2 Ride & Handling suspension - (OE P/N 25884700 – right side, 25884699 – left side). If the self leveling rear dampers are not replaced, the rear will not lower.