

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



SPORTLINE- # 4.2028

**Dodge, Chrysler, Plymouth - Neon, 4-door,
(Incl. R/T & ACR & SRT4 Models) 2000-2004**

Kit Contents	Description	Part Number	Qty
	Front Spring	4.2028F	2
	Rear Spring	4.2028R	2
	Front Bumpstop	770015	2
	Information Kit	EPAK	1
	Instructions	4.2028INST	1

NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands.
- **SPORTLINE** springs are marked with a .F, for Front and .R, for the Rear.
- **SPORTLINE** springs should be installed with the **Eibach** Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **SPORTLINE** Springs.
- After installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

ALIGNMENT:

After installation, it will be necessary to perform a full vehicle alignment. **Eibach** offers the following alignment kits for this vehicle.

Part #: 5.81260K

Front/ Rear: Rear

Camber Adjustment: +/-1.75°

Part #: 5.81250K

Front/ Rear: Front

Camber Adjustment: +/- 1.75°

Bump Stop Trimming Instructions

Typical Bump-Stop
(Bump-Stop from your vehicle may have different shape)

