

Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114



PRO-KIT Kit – 4011.140

Acura, 2.2 CL, 1996-1997

Acura, 2.3 CL, 1998-2000

Honda, Accord, 2 & 4-door & wagon, 4 Cyl; Exc. 6 Cyl; & Wag; 1990-1997

Kit Contents	Description	Part Number	Qty
	Front Spring	4011.201	2
	Rear Spring	4011.102	2
	Instructions	4011.140INST	1
	Information Kit	EPAK	1

NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- PRO-KIT springs are marked with a .001, for Front and .002, for the Rear.
- PRO-KIT springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the PRO-KIT Springs.
- After installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors
- Tire Rotation: In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

Alignment Kits:

After installation, it will be necessary to perform a full vehicle alignment. Eibach offers the following alignment kits for this vehicle:

Part #	Front or Rear	Camber Adjustment
5.84670K	Rear	+/- 0.5
5.84680K	Rear	+/- 0.75
5.84945K	Front	+0-1.25 degrees

Bump Stop Trimming Instructions

Typical Bump-Stop
(Bump-Stop from your vehicle may have different shape)

Acura 2.2 CL	96-97	30mm
Acura 2.3 CL	98>	30mm
Acura 2.5 TL	95-98	20mm
Honda Accord & Wagon	94-97	30mm

Front Bump Stop Trim Bottom:
(See Above List)

Acura 2.2 CL	96-97	None
Acura 2.3 CL	98>	None
Acura 2.5 TL	95-98	20mm
Honda Accord & Wagon	94-97	None

Rear Bump Stop Trim Bottom:
(See Above List)