

FLOWMASTER™

AMERICAN THUNDER™

**SYSTEM #17223
1994-1999 ACURA INTEGRA
FITS ALL 2 DOOR MODELS**

01/22/03

Removal:

- 1) Raise the vehicle up on a hoist or rack to working height. If you do not have access to a hoist or rack raise the vehicle and support securely with jack stands.
- 2) Support the muffler with a jack stand or muffler stand then separate the muffler hangers from the rubber mounts on the vehicle. A lubricant such as WD-40 or lithium grease may ease removal.
- 3) Use a 12mm wrench to remove the two bolts at the flange connection in front of the muffler, then carefully lower the stand and remove the muffler assembly from under the vehicle and set aside.

Installation:

- 1) Slide the inlet pipe of muffler assembly #952062-132 over the rear axle and into the same location as the stock muffler, tilt the muffler enough to allow the hangers to slide into the rubber mounts on the vehicle.
- 2) After the hangers are in the mounts, slide the muffler forward to connect the two flanges together, reinstall the two bolts and tighten securely.
- 3) Then place stainless tip #ST339 onto the muffler outlet and rotate until the tip is in the desired position. Firmly tighten the hose clamp on the tip to hold the tip in place. We highly recommend tack welding the tip to the muffler to prevent slippage and possible loss of the tip.

Packing List

Qty	Description	Part #
1	Muffler Assembly	952062-132
1	Stainless tip	ST339

FLOWMASTER AMERICAN THUNDER SYSTEM #17223
1994-99 ACURA INTEGRA, ALL 2 DOOR MODELS

