

FLOWMASTER™

AMERICAN THUNDER™

SYSTEM #17269

1996-1999 HONDA CIVIC

FITS 2 & 4 DOOR MODELS - EXCEPT 99 CIVIC SI

11/18/02

Removal:

- 1) Raise the vehicle up on a hoist or rack to working height. If you do not have access to a hoist or rack raise the vehicle and support securely with jack stands.
- 2) Support the muffler with a jack stand or muffler stand then separate the muffler hangers from the rubber mounts on the vehicle. A lubricant such as WD-40 or lithium grease may ease removal.
- 3) Use a 12mm wrench to remove the two bolts at the flange connection in front of the muffler, then carefully lower the stand and remove the muffler assembly from under the vehicle and set aside.

Installation:

- 1) Slide the inlet pipe of muffler assembly #952062-135 over the rear axle and into the same location as the stock muffler, tilt the muffler enough to allow the hangers to slide into the rubber mounts on the vehicle.
- 2) After the hangers are in the mounts, slide the muffler forward to connect the two flanges together, reinstall the two bolts and tighten securely.
- 3) Place the stainless tip onto the muffler outlet and adjust to the desired position, tighten the hose clamp securely. We highly recommend tacking the tip to the muffler outlet, this will prevent possible loss of the tip due to it vibrating loose.

Packing List

Qty	Description	Part #
1	Muffler Assembly	952062-135
1	Stainless Tip	ST339

FLOWMASTER AMERICAN THUNDER SYSTEM #17269

1996-99 HONDA CIVIC

FITS 2 & 4 DOOR MODELS - EXCEPT 99 CIVIC SI

